# ONN SAFE AUSTRALIA PTY LTD


ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: <a href="www.qnnsafe.com.au">www.qnnsafe.com.au</a>
Email: <a href="mailto:info@qnnsafe.com.au">info@qnnsafe.com.au</a>
Phone: 02-87982669

# **QNN**<sup>®</sup>Safe

# USER'S MANUAL FOR HG II SERIES SAFE





This package contents:

- User manual
- 2 Master keys
- 1 External Battery Box
- 2 Bolt Down Screws 12mmx80mm
- 4 AA Batteries
- 2 Emergency back up Keys

Please contact your retailer or Qnn Safe Australia P/L if any shortage occurred

## Model HG-6842II, HG-8045II, and HG-9150II has an internal

## hidden locker located at the bottom of the safe, with two keys

For the first time use, it needs the external battery power support:

- Insert the supplied 4 AA batteries into the External Battery Box
- Connect the power to the front panel. The power inlet is located behind the QNN nameplate. Slid the plate sideward will see the power inlet.

After the safe is opened, please replace the batteries into the internal battery box, which is located behind the door plate, please slid the box cover sideward to open.

- Prepare the master key into the position
- After enter the right code, turn master key clockwise and turn the handle knob clockwise, Safe is new unlocked. (For some model, just turn the master key to unlock the safe)

This safe is operated by the Master Key and the digital code.

The factory setting for the digital code is: "1 2 3 4 5 6 "

# ONN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: <a href="www.qnnsafe.com.au">www.qnnsafe.com.au</a>
Email: <a href="mailto:info@qnnsafe.com.au">info@qnnsafe.com.au</a>
Phone: 02-87982669

## **Opening instructions:**

- Prepare the master key into the position
- Touch the front screen to activate the system. INPUTE MODE appears. Enter the code, and then press ⊕. The "OPEN" displayed with two beeps. The door is ready for open. (Factory setting code "123456")
- Turn master key clockwise and turn the handle knob clockwise, safe now is unlocked. (For some model, just turn the master key to unlock the safe)
- Displayed "E-CODE" with 3 beeps means it is a wrong code try. 3 continual wrong code tries will lead the loudly sound alarm activated for 60 seconds and the operations will be held for 5 minutes.

Cautions: After the alarm is activated, there is no way to de-activate the alarm within the 60 seconds period. And also the operation is held for 5 minutes.

 Any unexpected sharking and moving toward the safe body will lead the loudly sound alarm be activated for 60 seconds

# **Closing instructions:**

- Close the door
- Turn handle knob counter clockwise (For some larger models)
- Turn master key counter clockwise, and remove the key.

## **Changing Code:**

Please keep the door at open position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening. Your code can be set up to 10 digits

- Open the safe door Press the reset button which is located behind the door plate, inside the battery box (slid the box cover sideward to open).
- "USER" then displayed
- Input your new own digital code (within 10 digits ), then press ⊕
- "AGAIN" then displayed.
- Input your new own digital code again, then press 

  to confirm
- "DONE" then displayed with one beep, which indicate that the code is changed successful
- Keep the door open, check and remember the code.

# ONN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: <a href="www.qnnsafe.com.au">www.qnnsafe.com.au</a>
Email: <a href="mailto:info@qnnsafe.com.au">info@qnnsafe.com.au</a>
Phone: 02-87982669

## **Emergency Backup**

In an emergency saturation, safe can be opened by the Master Key with the override Emergency key together. (Override the digital lock). The key whole is located next to the power inlet, hidden behind the QNN nameplate, to expose the key hole you need to peel off the black label and then screw off two screws, and take off the whole nameplate.

Turn the Emergency Key clockwise and then turn the master key clockwise to unlock the safe. (For some then turn the Handle / Knob to open the door)

#### Other features:

To activate system setting, it needs to enter the **SET MODE**. Touch the front screen to activate the system. Press for **Set Mode** appear, and then enter the code, and then press to confirm. Now, you can set "**Record, Time, Hide, Light, Code**" functions by press 0 to select and press to confirm.

#### • Record:

After entering the Record mode, press **0** to show the opening record. Maximum 100 records can be storied.

#### Set Day and Time:

After entering the Time mode, follow the flash cursor to set the Year, Month, Day, Hour, and Minute. Then press  $\oplus$  to confirm. Then press  $\otimes$  to exit

#### • Code hidden function:

After entering the Hide mode Press **0** to select ON, or OFF, and then press **⊕** to confirm. Then press **⊕** to exit

#### • Illumination when door is opened:

After entering the Light mode Press  $\mathbf{0}$  to select ON, or OFF, and then press  $\mathbf{\oplus}$  to confirm. Then press  $\mathbf{\odot}$  to exit

When ON is selected, light atomically turn on for 15 seconds after the door is opened. Light will goes off 3 seconds after door is locked

### **Cautions:**

- For security reason, Please do not story the Master Key with Emergency Key together.
- Do not store the Emergency Keys and the External Battery Box inside the safe.
- When the "LO-BAY" display with 3 beeps, it means that the batteries need to be replaced. Please replace new batteries as soon as possible.